

Quick-Start and Flushing Instructions



1. Remove water pitcher from box.



2. Remove lid and reservoir from the pitcher carafe.



3. Remove filter pack from inside reservoir.



4. Thread the red flushing disk tightly onto the filter pack (if not already assembled).



5. Press the flushing bulb onto a water faucet and run water for 4 to 5 minutes at low pressure.



6. Remove the red flushing disk and re-thread water filter to reservoir.



7. Insert reservoir back into carafe. Fill water pitcher with water from faucet.

Congratulations! Your water filtration pitcher is ready to use!

The filter lasts for approximately six months depending upon water usage and water quality. Usage with hard water or water contaminated with heavy minerals will shorten the life of the filter. You may notice a change in the taste of the water and/or restricted flow of the water when it's time to change the filter. Re-flush if necessary.